



M101RK

Rugged Android Tablet

ARM® Cortex™-A72 Quad-Core, 2.0 GHz

ARM® Cortex™-A53 Quad-Core, 1.5 GHz

Android 7.1



User Guide

Version 1.1

Please read these instructions carefully before using this product, and save this manual for future use

Contents

PREFACE	4
ADVISORY CONVENTIONS	4
SAFETY INFORMATION.....	5
HANDLING AND MAINTENANCE	7
DECLARATION OF CONFORMITY (DoC).....	8
ABOUT THIS USER GUIDE	9
CHAPTER 1: GETTING STARTED.....	10
1.1 UNPACKING	11
1.2 DESCRIPTION OF PARTS	13
1.3 FIRST-TIME OPERATION.....	14
1.3.1 <i>Installing SIM-Card (For 3G/LTE Equipped Devices)</i>	15
1.3.2 <i>Inserting MicroSD Card</i>	16
1.3.3 <i>Inserting Battery Pack</i>	16
1.3.4 <i>Connecting to Power Supply</i>	17
1.4 TURNING ON AND OFF THE DEVICE.....	17
1.4.1 <i>Turning On</i>	17
1.4.2 <i>Turning Off</i>	18
1.5 RESETTING TO FACTORY DEFAULTS	19
CHAPTER 2: USING THE TABLET	20
2.1 USING THE TOUCH SCREEN.....	21
2.2 WAKING UP THE TABLET.....	21
2.3 USING THE HOME SCREEN	22
2.3.1 <i>Personalizing Home Screen</i>	22
2.3.2 <i>Viewing other parts of the Home Screen</i>	24
2.4 STATUS AND NOTIFICATION ICONS.....	25
2.4.1 <i>Notification Icons</i>	25
2.4.2 <i>Status Icons</i>	25
2.5 USING THE ON-SCREEN KEYBOARD	26
2.5.1 <i>Entering Text</i>	26
2.5.2 <i>Editing Text</i>	27
2.6 DISPLAY SETTINGS	28
2.7 AUDIO PROFILE SETTINGS	29
2.7.1 <i>Sound Settings</i>	29
2.7.2 <i>Adjusting Volume</i>	29
2.8 LANGUAGE AND KEYBOARD SETTINGS	30
2.9 ABOUT PHONE.....	31
CHAPTER 3: WINMATE HOME MANAGER.....	32
3.1 HOW TO LOCK APPLICATIONS	33
3.2 HOW TO UNLOCK APPLICATIONS	35
3.3 HOW TO CHANGE PASSWORD.....	37
CHAPTER 4: NETWORKS AND WIRELESS DEVICES	38
4.1 CONNECTING TO MOBILE NETWORKS.....	39
4.1.1 <i>Checking the Network (GPRS/3G/4G) Connection</i>	39
4.1.2 <i>Turning on Data Service</i>	39
4.2 CONNECTING TO Wi-Fi NETWORKS	40
4.2.1 <i>Turning on Wi-Fi and Connecting to Wi-Fi Networks</i>	40
4.2.2 <i>Adding Wi-Fi Network</i>	41
4.3 CONNECTING TO BLUETOOTH DEVICES	42
4.3.1 <i>Turning Bluetooth On or Off</i>	42
4.3.2 <i>Connecting to Bluetooth Device</i>	42
4.3.3 <i>Disconnecting Bluetooth Device</i>	42
4.4 CONNECTING TO COMPUTER VIA USB	43

4.4.1 USB Computer Connection	43
4.4.2 USB Debugging Settings	44
CHAPTER 5: USING CAMERA.....	45
5.1 CAPTURING PHOTOS OR VIDEO	46
5.1.1 Opening Camera.....	46
5.1.2 Taking pictures	46
5.1.3 Viewing pictures	46
5.1.4 Shooting videos	47
5.2 THE GALLERY.....	47
CHAPTER 6: USING BARCODE READER.....	48
6.1 USING BARCODE READER.....	49
6.1.1 Barcode Reader Location.....	49
6.1.2 Android Winmate® Data Collection (WDC)	49
6.1.3 Where to Find WDC	49
6.1.4 How to Turn On/Off the Power of Barcode Reader	50
6.1.5 How to Change the Symbologies of Barcode.....	51
6.1.6 How to Add Command to the Barcode Output.....	51
6.1.7 How to Change the Scan Type of the Barcode Reader	52
6.1.8 How to Change Volume Button to Barcode Trigger Button.....	52
6.1.9 How to Change WDC Settings or Reset to Default	54
6.1.10 Scanning Barcodes.....	54
6.1.11 Scanning Tips and Considerations	55
6.2 REPLACING HOT SWAPPABLE BATTERY	56
6.3 DOCKING CONNECTOR PIN DEFINITION	56
APPENDIX.....	57
APPENDIX A: BASIC TROUBLESHOOTING	58
APPENDIX B: PRODUCT SPECIFICATIONS	60
APPENDIX C: ORDER INFORMATION.....	61
APPENDIX D: SOFTWARE DEVELOPMENT KIT	62
APPENDIX E: OS IMAGE UPDATE	62
APPENDIX F: OTA UPDATE GUIDE	63

Preface

Advisory Conventions

Four types of advisories are used throughout the user manual to provide helpful information or to alert you to the potential for hardware damage or personal injury. These are Notes, Important, Cautions, and Warnings. The following is an example of each type of advisory.

**Note:**

A note is used to emphasize helpful information

**Important:**

An important note indicates information that is important for you to know.

**Caution/ Attention**

A Caution alert indicates potential damage to hardware and explains how to avoid the potential problem.

Une alerte d'attention indique un dommage possible à l'équipement et explique comment éviter le problème potentiel.

**Warning! Avertissement!**

An Electrical Shock Warning indicates the potential harm from electrical hazards and how to avoid the potential problem.

Un Avertissement de Choc Electrique indique le potentiel de chocs sur des emplacements électriques et comment éviter les problèmes.

Safety Information



Precaution on Battery Pack Précaution avec le bloc-pile

Do Not Disassemble, Modify, or Insert Sharp Objects Into the Battery Pack. Electrolyte leakage, generation of heat, ignition or rupture may result.

[FR] Ne pas démonter, modifier, ou insérer des objets pointus à l'intérieur du bloc-pile. Une fuite d'électrolyte, la génération de chaleur, l'amorçage ou la rupture peuvent être occasionnés.

Do Not Short the Positive (+) and Negative (-) Terminals of the Battery. Generation of heat, ignition or rupture may result. When carrying or storing the device, do not place the battery pack together with articles that may contact electricity.

[FR] Ne pas court-circuiter les bornes Positive (+) et Négative (-) de la pile, la génération de chaleur, l'amorçage ou la rupture peuvent être occasionnés. Lors du transport et du rangement de l'appareil, ne pas placer le bloc-pile en même temps que des articles pouvant créer un contact électrique.

Do Not Apply Shocks to the Battery by Dropping It or Applying Strong Pressure to It. Electrolyte leakage, generation of heat, ignition or rupture of battery may occurs.

[FR] Ne pas faire subir de choc à la pile en la laissant tomber ou en appliquant une forte pression dessus. Une fuite d'électrolyte, la génération de chaleur, l'amorçage ou la rupture peuvent être occasionnés.

Do Not Charge the Battery Other Than Methods Those Specified In This Manual. If the battery is not charged using one of the specified methods, electrolyte leakage, generation of heat, ignition or rupture may result.

[FR] Ne pas charger la pile par d'autres méthodes que celles spécifiées dans ce manuel. Si la pile n'est pas chargée en utilisant l'une des méthodes spécifiées, une fuite d'électrolyte, la génération de chaleur, l'amorçage ou la rupture peuvent être occasionnés.

When the Battery Pack Has Deteriorated, Replace It with a New Battery. Continued use of a damaged battery pack may result in heat generation, ignition or battery rupture.

[FR] Lorsque la pile est détériorée, la remplacer par une nouvelle pile. L'utilisation continue d'une pile endommagée peut occasionner une génération de chaleur, l'amorçage ou la rupture de la pile.

Do Not Expose the Battery Pack to Excessive Heat, or Extreme Heat (Near Fire, in Direct Sunlight for example) Generation of heat, ignition or rupture may result

[FR] Ne pas exposer le bloc-pile à une Chaleur Excessive, ou une Chaleur Extrême (Près d'un feu, sous la lumière du soleil par exemple) Une production de chaleur, l'amorçage ou la rupture peuvent être occasionnés

Do Not Use the Battery Pack With Any Other Products. The battery pack is rechargeable and is only designed for this specific product. If it is used with a product other than the specified product, electrolyte leakage, generation of heat, ignition or rupture may result.

[FR] Ne pas utiliser avec un autre produit La batterie est rechargeable et a été conçue pour un produit spécifique. Si elle est utilisée sur un produit différent de celui pour lequel elle a été conçue, des pertes d'électrolytes et une production de chaleur sont possibles, elle risque également de prendre feu ou de casser.

Do Not Use This Product With Battery Other Than the One Specified.

[FR] Ne pas utiliser ce produit avec une batterie autre que celle spécifiée

Discontinue using device immediately if you notice the battery is swelling, or looks puffy or misshapen. Do not attempt to charge or use the device. Do not handle a damaged or leaking battery. Do not let leaking battery fluid come into contact with your eyes, skin or clothing.

[FR] Si vous remarquez une pile gonflée, élargie ou anormale, cesser l'utilisation de l'appareil immédiatement. N'essayez pas de recharger l'appareil ou de l'utiliser. Ne pas manipuler une pile qui fuit ou qui est endommagée. Ne laissez pas de liquide qui fuit entrer en contact avec vos yeux, votre peau ou vos vêtements.



General Product Safety Sécurité générale des produits

- Do not block any ventilation openings. Do not place the product against a wall or in an enclosed space as doing so might impede the flow of cooling air.
[FR] Ne pas bloquer les ouvertures de ventilation. Ne pas placer le produit contre un mur ou dans un espace clos de façon à entraver la circulation de l'air de refroidissement.
 - Do not place the product near any heat sources such as radiators, warm air intakes, stoves or other heat-generating devices (including amplifiers or other heat producing equipment).
[FR] Ne pas placer le produit près d'une source de chaleur comme des radiateurs, les arrivées d'air chaud, poèles ou autres produits générant de la chaleur (y compris les amplificateurs ou autre équipement produisant de la chaleur.)
 - Protect the power cord from being crushed or pinched, particularly in the area of the plugs, any receptacles used, and the point of exit from the apparatus. Do not break off the ground pin of the power cord.
[FR] Empêcher le cordon d'alimentation d'être écrasé ou pincé, en particulier dans les zones de prises, des containers utilisés, et du point de sortie de l'appareil. Ne pas casser la broche de terre du cordon d'alimentation.
 - Do not disregard the safety that a polarized or grounded connection can provide. A polarized connection consists of two plugs, one of which is larger than the other. A grounded connection has two blades and a third one that is grounded. If the main plug provided cannot be inserted into your outlet, consult an electrician to replace your obsolete outlet.
[FR] Ne pas ignorer la sécurité qu'une prise polarisée ou une prise de terre peut prévoir. Une prise polarisée se compose de deux fiches, dont l'une est plus large que l'autre. Une prise de terre possède deux lames et une troisième qui est la terre. Si la fiche principale fournie ne peut être insérée dans votre prise, consultez un électricien pour remplacer votre prise obsolète.
 - Use only accessories specified by the manufacturer.
[FR] Utiliser uniquement les accessoires spécifiés par le fabricant.
- This product should not be used near water such as bathtubs, sinks, swimming pools, wet basement, etc.
[FR] Ce produit ne doit pas être utilisé près de l'eau comme les baignoires, les éviers, les piscines, les sous-sols humides, etc.
 - Use only with its transport carriage, stand, tripod, console or table specified by the manufacturer or sold with the product. When using a carriage, move the carriage assembly with the product carefully to avoid damage from falling over.
[FR] Utiliser uniquement avec son chariot de transport, support, trépied, console ou table spécifiés par le fabricant ou vendu avec le produit. Lors de l'utilisation d'un chariot, déplacez l'ensemble chariot avec le produit avec soin pour éviter tout dommage de chute.
 - Unplug this apparatus during lightning storms or when it is not being used for long periods.
[FR] Débrancher cet appareil durant les orages ou lorsqu'il n'est pas utilisé pendant de longues périodes.
 - Refer all servicing to qualified service personnel. A technical intervention is required when the apparatus has been damaged in any way, for example if the power cord or plug is damaged, liquid has been spilled or objects have fallen inside the unit, if the product has been exposed to rain or moisture, if it does not operate normally or if it has been dropped.
[FR] Confier toute réparation à du personnel qualifié. Une intervention technique est nécessaire lorsque l'appareil a été endommagé de quelque façon, par exemple si le cordon d'alimentation ou la fiche est endommagé, du liquide a été renversé ou des objets sont tombés à l'intérieur de l'unité, si le produit a été exposé à la pluie ou à l'humidité, s'il ne fonctionne pas normalement ou s'il a été jeté.



General Guideline Directive générale

It is recommended to reboot the device when some functions are defect or inactive. If it still can't solve the problems please contact your dealer or agent.

Il est recommandé de redémarrer l'appareil lorsque certaines fonctions sont défectueuses ou inactives. Si le problème persiste, veuillez contacter votre revendeur ou votre agent.

Handling and Maintenance



General Guideline Guide Général

Keep the product at least 13 cm (5 inches) away from electrical appliances that can generate a strong magnetic field such as TV, refrigerator, motor, or a large audio speaker.
[FR] Garder le produit au moins à 13 cm (5 pouces) de distance des appareils électriques qui peuvent générer un fort champ magnétique comme une télévision, un réfrigérateur, un moteur, ou un important haut-parleur.

Do not place heavy objects on top of the tablet computer as this may damage the display.
[FR] Ne pas placer d'objets lourds sur le dessus de l'ordinateur tablette cela peut endommager l'écran.

The screen surface can be easily scratched. Use with care. Do not use paper towels to clean the display but use the included cleaning cloth. Avoid touching it with a pen or pencil.
[FR] La surface de l'écran peut être facilement rayée. Utiliser avec précaution. Ne pas utiliser de serviette en papier pour nettoyer l'écran mais utiliser le chiffon de nettoyage inclus. Éviter de toucher avec un stylo ou un crayon.

To maximize the life of the backlight in the display, allow backlight to automatically turn off as a result of power management. Avoid using a screen saver or other software that prevents the power management from working.
[FR] Pour maximiser la durée de vie du rétroéclairage de l'écran, autoriser le rétroéclairage résultant de la gestion de l'alimentation. Éviter d'utiliser un économiseur d'écran ou un autre logiciel empêchant la gestion de l'alimentation de fonctionner.



Cleaning Guideline Guide de nettoyage

Use a soft cloth moistened with water or a non-alkaline detergent to wipe the exterior of the product.
[FR] Utiliser un chiffon doux humidifié avec de l'eau ou un détergeant non alcalin pour essuyer l'extérieur du produit.

Gently wipe the display with a soft, lint-free cloth. Do not use alcohol or detergent on the product.

[FR] Essuyer délicatement l'écran avec un chiffon doux non pelucheux. Ne pas utiliser d'alcool ou un détergent sur le produit.



Touchscreen Guideline Guide de l'écran tactile

Use your finger or the stylus on the display. Using sharp or metallic object may cause scratches and damage the display, thereby causing errors.

[FR] Utiliser votre doigt ou le stylet sur l'écran. L'utilisation d'un objet pointu ou métallique peut provoquer des rayures.

Use a soft cloth to remove dirt on the display. The touchscreen surface has a special protective coating that prevents dirt from sticking to it. Not using a soft cloth may cause damage to the special protective coating on the touchscreen surface. To clean off hard to remove dirt, blow some steam on the particular area and gently wipe away using a soft cloth.

[FR] Utiliser un chiffon doux pour enlever la poussière sur l'écran. La surface de l'écran tactile a un revêtement protecteur spécial empêchant la saleté de se coller à lui. Ne pas utiliser un chiffon doux peut endommager le revêtement spécial sur la surface de l'écran tactile. Pour nettoyer les saletés plus difficiles à enlever, souffler de la buée sur la zone particulière et essuyer doucement avec un chiffon doux.

Do not use excessive force on the display. Avoid placing objects on top of the display as this may cause the glass to break.

[FR] Ne pas utiliser une force excessive sur l'écran. Éviter de placer des objets au dessus de l'écran cela pourrait provoquer une cassure du verre.

When there is a noticeable discrepancy in the operation of the touchscreen function (your touch does not correlate to the proper location on the screen), recalibrate the touchscreen display.

[FR] Lorsqu'il y a un écart sensible dans le fonctionnement de l'écran tactile (votre contact ne correspond pas à la bonne position sur l'écran), recalibrer l'écran tactile.

Declaration of Conformity (DoC)

FCC Statement

This device complies with part 15 FCC rules.



Operation is subject to the following two conditions:

- This device may not cause harmful interference.
- This device must accept any interference received including interference that may cause undesired operation

This equipment has been tested and found to comply with the limits for a class "B" digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

CE Notice (European Union)



Electromagnetic Compatibility Directive (2014/30/EU)

- EN55024: 2010/ A1: 2015
 - IEC61000-4-2: 2009
 - IEC61000-4-3: 2006+A1: 2007+A2: 2010
 - IEC61000-4-4: 2012
 - IEC61000-4-5: 2014
 - IEC61000-4-6: 2014
 - IEC61000-4-8: 2010
 - IEC61000-4-11: 2004
- EN55032: 2012/AC:2013
- EN61000-3-2:2014
- EN61000-3-3:2013

Low Voltage Directive (2014/35/EU)

- EN 60950-1:2006/A11:2009/A1:2010/A12:2011/ A2:2013

This equipment is in conformity with the requirement of the following EU legislations and harmonized standards. Product also complies with the Council directions.

About This User Guide

This User Guide provides information about using the Winmate® M101RK and accessories.

**Note:**

Some pictures in this guide are samples and can differ from actual product.

Documentation Set

The documentation set for the M101RK provides information for specific user needs, and includes:

- **M101RK Series Quick Start Guide** - describes how to get the M101RK up and running.
- **M101RK Series User Guide** – contains detailed description on how to use the M101RK, its components and features.

Chapter Descriptions

[Chapter 1, Getting Started](#) provides basic instructions on how to use M101RK, including main SIM card, SD card and battery installation, powering on and resetting M101RK.

[Chapter 2, Using the M101RK](#) provides basic instructions on using the M101RK.

[Chapter 3, Using Winmate Home Manager](#) explains how to use WHM to lock the launcher.

[Chapter 4, Connecting to Network and Devices](#) explains how to connect M101RK to networks, Bluetooth devices, and computer.

[Chapter 5, Using Camera](#) provides instructions on how to use camera on M101RK.

[Chapter 6, Capturing Data](#) provides information on how to use Barcode Reader that might be present in M101RK.

[Chapter 7, Accessories](#) describes the available accessories and how to use them with the M101RK.

Chapter 1: Getting Started

This chapter tells you information about Winmate® M101RK Series tablet, its highlighted features, and provides basic instructions for using the M101RK, including powering on and resetting the M101RK.

1.1 Unpacking

Check and identify the standard supplied accessories.

Standard factory shipment list:

- **Tablet Computer**



- **Power Adapter**



- **Standard Battery**

P/N: 98K000A000AC




- **Power Cord and Plugs**



- **Capacitive Touch Stylus**

P/N: 9B000000001D



- **Quick Start Guide**



Optional Accessories

Your package may include optional accessories based on your order.

You can purchase optional accessories for M101RK from Winmate:

Carry Bag

P/N: 9B000000003J

- With hand carrier and shoulder strap
- Separated pocket for accessories

Hand Strap

P/N: 98K000A0003J

- Ergonomic hand-strap can help you handle the Rugged Tablet much more easily and comfortably.

Battery Charger

P/N: 98KT00A0000F

- Dual charging slots.
- LED indicators to show current battery charging status.

Vehicle Dock

P/N: 98K000A0003L

- VESA Mounting support
- 2 x USB 2.0 (2 x Rear,)
- 1 x LAN (10/100)
- 1 x RS232
- 1 x GPS ANT SMA
- 9-36V DC IN with 3-pin terminal block
- Easy insert and release with Key-Lock

Desk Dock

P/N: 98K000A00052

- 2 x USB 2.0 (2 x Rear)
- 1 x LAN (10/100)
- 1 x VGA
- 1 x RS232

Shoulder Strap

P/N: 98K000A0003Q

- Fixed with screws
- Adjustable cross-body strap (85-165cm) with pad


VESA Mount Kit

P/N: 98KT00A0001H


- Widely used mounting solution

1.2 Description of Parts

Front:



Right:




No	Item	Description
1	Front Camera	2 Megapixel Webcam
2	LED Indicators:	Show the current status of the Tablet Computer Red: Charging / Hot-swap battery Green: Full Charge Blue: Turning on
3	Touch Screen	Display and act as one of the inputs for the Tablet Computer
4	Back Button	Back to previous page
5	Home Button	Back to Desktop
6	Power Button	Power on/off
7	I/O Cover	Protects I/O ports

Front LED Indicators Details:






Front Button Details:



No	Item	Description
8	Micro HDMI	HDMI Output
9	Micro SD Card Reader	Memory card reader port for Micro SD Card.
10	USB Type C	High speed USB port connects to PC or USB devices such as mouse, keyboard, etc. Note: The USB Type-C connector follows USB 3.0 standard and support Dual Role port (DRP), which does not support Alternate Mode (ALT) or USB Power Delivery (USB-PD).
11	USB 3.0 Host	High speed USB port connects to PC or USB devices such as mouse, keyboard, etc. Note: This USB port won't work when the tablet is connected to the optional docking. Please use the USB ports on the docking.
12	Mic In/Line Out	Headset or headphone can be connected
13	Power Jack	DC-IN power input jack

Side I/O Details:



Rear:**Bottom:**

No	Item	Description
14	NFC	Optional NFC reader for reading of NFC tags.
15	Kensington Lock Port	Provide lock access for Kensington Lock.
16	Expansion Port	Provide optional connectivity to custom modules for special application (USB2.0, RS232).
17	Rear Camera	5MP Autofocus Camera. Captures photos and videos.
18	Optional Barcode	Barcode Scanner for reading of 1D / 2D barcode.
19	Fn Button	Menu.
20	Volume Control or Scan Buttons	Volume Control (+) Raise volume, (-) Lower volume. Scan Button Use WDC to change button definition (+)/(-) for scanning
21	Speakers	Emits sounds
22	3G / LTE Module (Optional) / SIM card slot	Service window to insert Micro SIM card. Also provide access to 3G / LTE Module.

No	Item	Description
23	Battery Lock Latch	Latch to lock the battery in place once battery is inserted. No spring loaded.
24	Touch Pen Slot	Pen holder slot to store touch pen.
25	Battery Release Slider	Spring-loaded slider that latches the battery in.
26	Docking Connector	Port to docking solutions such as vehicle docking to provide power and external antenna.

1.3 First-Time Operation

To get started:

1. Install SIM card (For 3G/LTE equipped devices).
2. Install memory card.
3. Install the battery.
4. Charge your tablet.
5. Start the tablet.


1.3.1 Installing SIM-Card (For 3G/LTE Equipped Devices)

The Tablet Computer supports 3G/LTE data connection and fits a Micro-SIM card.


To install the SIM card:

Tools Needed:	Service Windows	3G/ LTE Module
	Screw: M2x5, 4 pc Screwdriver: Philips Type , Size #0 , for M2 screws, torque: 2.0 ± 0.5 kgf.cm	Screw: M2x3.5, 1 pc Screwdriver: Philips Type , Size #0 , for M2 screws, torque: 2.0 ± 0.5 kgf.cm


- ① Remove four screws and remove the service window.




- ③ Carefully flip and move the 3G/ LTE module and to the right. **Do not disconnect cables!**




- ⑤ Use your hand to carefully pull the cable outside the module card. Re-insert the 3G/LTE module and fasten one screw. Accurately route the cables. **Do not bend cables! Do not pinch/ squeeze the cable!**




- ② Remove the one screw that secures the 3G/ LTE module. Carefully lift the module up. **Do not damage the connected cables!**



- ④ Insert SIM-Card all the way in. **Chip/ contact facing down.**



- ⑥ Re-insert the service window and fasten with the four screws.



Caution/ Attention

When re-inserting 3G/LTE module, please pay attention to cable routing. Make sure the cable module does not get squeezed.



Lors de la réinsertion du module 3G / LTE, veillez au routage des câbles. Assurez-vous que le module ne soit pas comprimé.

1.3.2 Inserting MicroSD Card

Your tablet supports *Micro SDXS card*.

To install Micro SDXS card:

1. Open I/O protective cover by pulling out the latch.
2. Insert microSD card into slot with contacts facing down.
3. Press the card in to ensure that it is seated properly.
4. Close I/O protective cover.



To remove Micro SD Card:

1. Open I/O protective cover by pulling out the latch.
2. Push and release the micro SD card to unlock it.
3. Pull out the micro SD card.

1.3.3 Inserting Battery Pack



Warning!

Discontinue using device immediately if you notice the battery is swelling, or looks puffy or misshapen. Do not attempt to charge or use the device. Do not handle a damaged or leaking battery. Do not let leaking battery fluid come into contact with your eyes, skin or clothing.





Caution

To keep battery health and prevent possible issues from battery over-discharged, please charge the tablet built-in back-up battery once every two months.

To insert the standard battery pack:

1. Disconnect AC adapter and power cord from the tablet computer.
2. Turn the tablet computer over, back facing up.
3. Locate the Battery Lock Latch and push it to the "Unlocked" position.
4. Locate the Battery Release Slider that is spring-loaded. Pull back and hold.
5. Insert the battery on the connector-pins side first, and then lower the battery into the battery compartment. Continue to hold the Battery Release Slider before battery is fully inserted.
6. Make sure the battery is completely lowered into the compartment before letting go the Battery Release Slider. Battery will be flat against the housing once fully inserted.



Removing the Battery Pack

1. Power off the tablet computer (or put it to sleep). Disconnect any cords connected to the computer.
2. Turn the tablet computer over, back facing up.
3. Locate the Battery Lock Latch and push it to the “Unlocked” position.
4. Locate the Battery Release Slider that is spring-loaded. Pull back and hold.
5. Lift the battery out using the opening on side of battery compartment.

1.3.4 Connecting to Power Supply

The Tablet Computer operates either on external AC power or internal battery power.

It is recommended to use AC power when you start up the Tablet Computer for the first time.

Caution



 Use only the AC adapter included with your Tablet Computer. Using other AC adapters may damage the Tablet Computer and the Battery.

Caution

 For users start up the Tablet Computer for the first time with internal battery power, please make sure the battery is fully charged before using.

Perform the following to connect the Tablet computer to AC Power:

1. On the side of the Tablet computer, lift the I/O protective cover by pulling on the latch
2. Plug the DC cord of the AC adapter into the Power Jack of the tablet computer.
3. Plug the AC power cord into the AC adapter.
4. Finally, Plug the AC power cord into the electrical outlet.



When the AC Adapter is connected, the battery pack starts charging. The battery LED indicator on the tablet computer would show different states. Please refer to description of LED indicator on Description of Parts.

Standard Battery	
Battery Operating Time	8 Hours
Battery Charging Time	2.5 Hours

1.4 Turning On and Off the Device

This section describes how to turn on/ off the device.

1.4.1 Turning On


1. Press and hold the power button for 3 seconds, located on the top side of the unit.
 2. When the device vibrates, release the power button.
- The desktop screen is displayed.

**Note:**

For power saving purpose, please enable Connect to PC in Accessibility settings.
When connected to PC external 4G, USB and LAN on Docking will be disabled.

1.4.2 Turning Off


1. To turn off the device, press and hold the power button until the phone options menu appears, tap the **Power Off**.
2. User can also use the Phone options menu to put the device into silent or airplane mode, see features table.



1.5 Resetting to Factory Defaults

To reset the device to factory defaults:

1. Tap **Menu**  , than tap **Settings** .
2. In the **Personal** tab, tap **Backup & Reset**.
3. User can select to back up application data, Wi-Fi passwords and other settings to Google servers by tapping **Backup My Data**.
4. Tap **Factory Data Reset** to reset the phone.



5. Read all the available information and then check Erase phone storage if user wants to erase all the data on the phone storage such as music or photo.

Chapter 2: Using the Tablet

This chapter explains how to use the buttons, status icons, and controls of M101RK tablet running on Android 7.1 Operating System and provides instructions on entering and capturing data.

2.1 Using the Touch Screen

The touchscreen supports the core gestures for Android.

Gesture	Action	Description
Tap		To select or activate something
Tap & Hold		Touch and hold an item on the screen by touching it and not lifting your finger until it responds
Touch, Hold & Drag		Touch and hold an item for a moment and then without lifting your finger, move your finger on the screen until you reach the target position. i.e. moving the apps around the home screen
Swipe or slide		Quickly move the finger across the surface of the screen. i.e. slide a lock screen to open the lock
Double-tap		Tap quickly twice on a webpage, screen, or App to zoom
Scale		Place two fingers on the screen and pinching them together

2.2 Waking Up the Tablet


If you do not use the tablet for a while, the screen dims and then darkens to conserve the Battery. To wake up the tablet:

1. Press the Power button on the top side of the tablet.
2. Drag the lock icon  upwards to unlock the screen.



2.3 Using the Home Screen

Home screen is the starting point to access all the features on your tablet Device. It displays application icons, widgets, shortcuts, and other features. User can personalize the home screen. See “Personalizing home screen”.




2.3.1 Personalizing Home Screen

User can add application icons, shortcuts, widgets, and other items to any part of any Home screen where there is free space. User can also switch the wallpaper.


To change wallpaper on the HOME SCREEN:

1. Tap **MENU**  , and then open **Settings** .
2. In the Device tab, tap **Display > Wallpaper**.
3. In the Wallpaper menu select the location of wallpaper, and then tap the type of item you want to add.




To move an item on the HOME SCREEN:

1. Tap and hold the item you want to move, until it can be moved.
2. Drag it to a new location on the screen.
3. Place the item where you want to put it and lift your finger.


**To remove items from the HOME SCREEN:**

1. Tap and hold the item you want to remove. The launcher icon will show **Remove** on the top of the screen.
2. Drag the item you want to remove to the Remove icon.
3. When the icon turns red, release your finger.




2.3.2 Viewing other parts of the Home Screen

1. Slide your finger left or right across the Home screen. Extensions to the Home screen provide extra space for APPS, shortcuts, and other items.



2. Tap the launcher icon  to view the entire APPS of the device.



The status bar appears at the top of every screen. On the left are notification icons and on the right are status icons, along with the current time.

2.4 Status and Notification Icons



Notification icons



Status Icon

2.4.1 Notification Icons

Pull down from the left top of the screen to get the notifications area. The following icons indicate that you have received notification.

	New email message		Incoming call
	New text or multimedia message		Missed call
	Alarm is set		Speakerphone is activated
	Upcoming event		Phone microphone is muted
	Data is syncing		Downloading data
	Problem with sign-in or sync		Phone is connected via USB cable
	A screenshot is captured		

2.4.2 Status Icons

Pull down from the right top of the screen to get the notifications area. The following icons indicate the status of your device, for example if users are connected to a Wi-Fi network that is not connected to the internet, the network icons are appears in white color.

Status icons that appear in the status bar are as follows:


	Connected to GPRS mobile network		Bluetooth is on
	Connected to 1xRTT mobile network		Connected to a Bluetooth device
	Connected to EDGE mobile network		No SIM card installed
	Connected to 3G mobile network		Vibrate mode
	Connected to 4G mobile network		Ringer is silenced
	Mobile network signal strength		Battery is very low
	Searching for a network signal		Battery is low
	No signal		Battery is partially drained
	Connected to a Wi-Fi network		Battery is full
	Roaming		Battery is charging
	Airplane mode		Receiving location data from GPS

2.5 Using the On-Screen Keyboard

User will be able to enter text using the On-Screen Keyboard. Some applications will launch the keyboard automatically. In others, user needs to touch a text field where user wants to enter text to launch the keyboard.


2.5.1 Entering Text

1. Open a text field, in this example we used Messaging  to compose a message. The On-Screen Keyboard opens.



**If user taps in a text field which already contains text, the insertion point is set where user tap and the cursor appears. User can drag the cursor to pick exactly where you want to add more text. User can also select a word to copy, cut and paste it. See "[Editing Text](#)".*

2. Tap the delete key  to erase characters to the left of the cursor.
3. Tap  to enter numbers. Tap  to return to letters.
4. To enter symbols and other characters, tap and hold one of the top-row keys and slide your finger up to the list of the options. Lift your finger when you find your selection.
5. To view additional symbols, tap  on the numeric keyboard.




6. To close the On-Screen keyboard, press the back button .

2.5.2 Editing Text

To select text:

1. Double-tap the text you want to select.
2. Tap  to select all the sentences in the menu that appears, the selected text is highlighted in blue, with a tab at each end of the selected word.
3. Drag selection tab to expand or reduce the range of the selected text.




To Cut or Copy Text:

1. Select the text to cut or copy, see the section above "To select text".
2. Tap  or  in the Edit text menu.
3. If you select  , the selected text is removed from the text field; it is stored in temporary area so that you can paste it into different text field.

To Paste Text:

1. After Cut or Copy the text, see the section above "To Cut or Copy Text"
2. Place the cursor in the text field where you want to paste the text, user can paste text that you copied from one application into a text field in any application.
3. Tap and hold into the location that you want to paste. Tap **PASTE** in the menu that opens or user


 can also tap  to replace the existing text with copied text.



2.6 Display Settings

Use the display settings to configure brightness and other screen settings.

1. Tap **MENU**  and then tap **Settings** .
2. In the **Device** tab, tap **Display**:
 - **Display**
 - **MiraVision™** - to display picture quality optimization options.
 - **Brightness level** – for adjusting the brightness of the screen.
 - **Adaptive brightness** – to optimize brightness level for available light
 - **Wallpaper** – to select wallpaper
 - **Sleep** – to set up the device's sleep mode after the specified period of inactivity
 - **Press power button twice for camera** – Quickly open camera without unlocking your screen.
 - **Battery Percentage** – to control battery percentage display.
 - **Screen saver** – to control what happens when the tablet is docked and/or sleeping, turn screen saver on
 - **Font size** – Make the text on screen smaller or larger
 - **Display size** – Make the items on your screen smaller or larger.
 - **When device is rotated** – for switching the orientation of the screen when user turns the device sideways or upright.
 - **Cast** – allows displaying whatever is visible on the device's screen on another screen, mostly wirelessly using Wi-Fi as a medium for sharing the screen.



Note:


For the longest battery life between charges, use the shortest Sleep time.

2.7 Audio Profile Settings

Use the sound settings to configure how and at what volume the tablet rings, vibrates or alerts user in other ways when user receive a call, receive a notification or an alarm sounds.

2.7.1 Sound Settings

1. Tap **MENU**  and then tap **Settings** .
2. In the **Device** tab, tap **Sound & Notification** and then user can select General, Silent, Meeting or Outdoor profile.



2.7.2 Adjusting Volume

1. Press the volume keys to change the ring volume (On Home screen) or earpiece volume (during a call).




2. Press the volume key to set up Vibration mode.



2.8 Language and Keyboard Settings

Use the Language & keyboard settings to select the language for the text on your tablet and for configuring On-Screen Keyboard, including words that you have added to its dictionary.

1. Tap **MENU**  and then tap **Settings** .
2. In the **Personal** tab, select **Language & Input**.
 - **Language** – to open the language screen, where user can select the language to use for the text on the device.
 - **Spell Checker** – to activate Android Spell Checker (AOSP) and check to correct misspelled words.
 - **Personal dictionary**– to open a personal dictionary.
 - **Keyboard & input methods**
 - **Virtual Keyboard** – to apply the onscreen keyboard that is included with user's device. Default Android Keyboard (AOSP).
 - **Physical Keyboard** – allows the user to apply physical keyboard settings if connected.
 - **Appearance & layouts**
 - **Theme** – to select the theme of layout.
 - **Custom input styles** – user can select custom input style, such as QWERTY keyboard.
 - **Enable split keyboard** – toggle to activate split keyboard layout.
 - **Text Correction**
 - **Personal dictionaries**
 - **Add-on dictionaries**
 - **Block offensive words** – disable suggesting potentially offensive words
 - **Auto-correction** – spacebar and punctuation automatically correct mistyped words.
 - **Show correction suggestions** – display suggested words while typing.
 - **Personalized suggestions** – learn from your communications and typed data to improve suggestions.
 - **Suggest contact names** – use names from Contacts for suggestions and corrections.
 - **Next-word suggestion** – use previous word in making suggestion.
 - **Advanced**
 - **Keypress vibration duration**
 - **Keypress sound volume**
 - **Key long press delay**
 - **Emoji for physical keyboard**
 - **Show app icon**



Changing the Keyboard Language

The current keyboard language is displayed on the Space key and user can switch languages.

1. Tap and hold the space key
2. Without lifting the finger, slide it to the left or right until the language you want to use appears in the center of the small window above the Space Key.
3. Lift the finger to change the keyboard language.


2.9 About Phone

About Phone includes information about user's device.

- **System Update** — provides information regarding the local or online update of your devices.
- **Status** — opens the status screen with a list of information about battery, network, signal strength and other details.
- **Legal Information** — lists details about the model number, Android Version, Baseband version etc. this information is useful if user need to work with support team.
- **Model number** – displays the model name of the current device.
- **Android version** – displays the current Android operating system version the device running

To access the information about the phone:

1. Tap **MENU** 
2. Tap **Settings** 
3. Scroll down to **System**, and then tap **About phone**.



Chapter 3: Winmate Home Manager


Every M101RK series tablet comes with preinstalled APP named Winmate® Home Manager (WHM). This application lets the device manager to lock the launcher. When the launcher is locked the user can only use one application assigned by the device manager.



3.1 How to Lock Applications

Step 1

- In the main APPS window, select the Home Manager APP and enable it.
- Select Home Manager to start your settings.
- Go to **Password Manager** and set your own password for this APP. The default password is “**0000**”.



Step 2


- Go to “**Application Selector**” and choose an Application to be locked.

Example: Select the Calendar AP.




Step 3 Go back to “**Home Selector**” and press “**Clear and Reset Default Home**”.

Step 4 Select “**Restrict Home**”, and then restart the tablet.




Step 6 System will ask to select “**Just once**” or “**Always**” to use this launcher, please select “**Always**”.




The system will automatically start the application which you selected and lock it.

Any time you press home key or back key, the system will go back to the same application which you have selected.




3.2 How to Unlock Applications

Step 1 Slide down the top bar and press “Home Manager” icon then you can find the menu and please enter the password to login (The default password is “0000”).



Step 2 Go back to “Home Selector” and press “Clear and Reset Default Home”.




Step 3 Restart the system and you will go back to the normal Launcher.




3.3 How to Change Password

Step 1 Go to **Password Manager** and set your own password for this APP.



Step 2 The default password is "**0000**". Enter a new password in **New Password field**, and then tap **Change Password**.



Chapter 4: Networks and Wireless Devices

This chapter explains how to connect tablet to network and peripheral devices.

4.1 Connecting to Mobile Networks

When users install a SIM card from service provider to the M101RK, the device is configured to use the provider's networks for voice calls and for transmitting data. Different locations may have different mobile networks available; user may need to configure M101RK to use certain networks.

**Note:**

To obtain faster networks configure the device to 4G.
To extend the life of battery user can use 2G network.

4.1.1 Checking the Network (GPRS/3G/4G) Connection

1. Tap and then tap **System Settings**
2. Tap **More** in the **Wireless & networks**, and then tap **Mobile networks**.
3. Tap **3G/4G Service** to check the network connection.

**Important:**

Do not change the parameters of the access point to prevent inability to access network sources.


4.1.2 Turning on Data Service

1. Tap **MENU** and then tap **Settings**
2. Tap **More** in the **Wireless & networks**, and then tap **Cellular networks**.
3. Tap **Data connection**.
4. Select the desired network operator to enable the data connection.

4.2 Connecting to Wi-Fi Networks


4.2.1 Turning on Wi-Fi and Connecting to Wi-Fi Networks

1. Tap **MENU**  and then tap **Settings** .
2. Tap **Wireless & networks** and then select **Wi-Fi** to turn it on .
3. Tap **Wi-Fi**. The device scans for available Wi-Fi networks and displays the list of it. Secured networks are indicated with a lock icon. If the tablet finds a network that you have connected previously, it connects to it automatically.
4. Tap a network to connect to it:
 - If the network is open, you are prompted to confirm that you want to connect it by tapping **Connect**.
 - If the network is secured, users are prompted to enter a password or other credentials.
5. To check the details about the speed, security, address and related settings, tap its name in the Wi-Fi settings screen.



4.2.2 Adding Wi-Fi Network

1. Turn on Wi-Fi, in the Wi-Fi settings screen, tap **+ Add network** (at the bottom of the list of discovered networks).
2. Input the SSID (name) of the network, if the network is secured, tap the security menu and then tap the type of security deployed on the network.
3. Enter any required security credentials.
4. Tap **Save**.




4.3 Connecting to Bluetooth Devices

4.3.1 Turning Bluetooth On or Off

1. Tap **MENU**  and then tap **System settings** .
2. Tap **Wireless & networks** and then select **Bluetooth**.
3. Toggle the on/off switch on the top-right hand side to turn on **Bluetooth**.

4.3.2 Connecting to Bluetooth Device

1. Go to **Settings** .
2. Tap **Wireless & networks**, and then tap **Bluetooth**.
3. Toggle the on/off switch on the top-right hand side to turn on Bluetooth.
4. It will automatically scan and displays the IDs of all available Bluetooth devices in range.
5. Tap the **ID** of the other device in the list in Settings to pair them.



4.3.3 Disconnecting Bluetooth Device

1. Tap the device in the Bluetooth settings screen.
2. Tap **OK** to confirm that you want to disconnect.

4.4 Connecting to Computer via USB

User can connect their tablet to a computer with USB cable to transfer files between tablet and computer.




Important:

- When connecting your tablet to a computer and inserting its USB storage or SD card, user must follow the computer's instructions for connecting and disconnecting USB device, to avoid damaging or corrupting files.
- Notice that the M101RK cannot be charged via USB.

4.4.1 USB Computer Connection

1. Enter setting menu, and enter select “Accessibility”, and then check “Connect to PC”.

When **Connected to PC** is selected:




	Check	Uncheck
Micro USB-OTG	V	X
Micro USB-Host	V	V
External 4G (U-blox) (If equipped)	X	V
Docking (USB & LAN)	X	V


2. Connect tablet to the computer via USB connector.



3. In the notifications area **USB connected sign** will appear.
4. Pull down the notification area to open notification panel.




5. Tap this icon  to choose the type of USB connection.
- **Transfer files** – let user transfers files between computer and tablet.
 - **Transfer photos (PTP)** – let users transfer photos or media files if MTP is not supported.
 - **Use device as MIDI** – let users use device as MIDI




4.4.2 USB Debugging Settings

To permit debugging tools on a computer to communicate with User's tablet via USB Connection.

1. Connect tablet to the computer via USB cable.
2. In the notifications area **USB debugging connect** sign  will appear.
3. Pull down the screen to open notification panel.



4. Tap **USB debugging connected**.
5. In the **Developer options** user can choose the action to perform.



Important:

Carefully follow your computer's instructions to un-mount the USB storage or SD card. Disconnect USB device not properly can cause a loss of important data or information.

Chapter 5: Using Camera

This chapter explains how to use camera to capture photos and videos.

5.1 Capturing Photos or Video

Winmate® M101RK is equipped with an 8MP Camera on the rear side and a 2MP Camera on the front side, which user can use to capture photos or video.

5.1.1 Opening Camera

1. Tap the launcher and then tap **Camera** .

Camera opens in Portrait mode, ready to take a picture or shoot a video.




Important:

Make sure the protective lens cover is clean before taking pictures. A lens cover with smudges from fingers can cause blurry pictures.

5.1.2 Taking pictures

1. Adjust the exposure, flash, and other necessary settings. Or leave it automatic.
2. Tap the On Screen Shutter icon .
3. The camera brings the image into focus, when the image is in focus, the focus indicators in each corner will turn green and ready to capture.
4. Tap  to change camera settings.



5.1.3 Viewing pictures

1. After taking a photo, a thumbnail of the picture is shown on the corner of the capture screen. Tap the thumbnail to view it.
2. Tap the onscreen button:



to share a photo.



to share through Bluetooth



to edit the photo



For more Camera options such as Delete, Edit, Rotate, Crop or photo details.


3. Swipe right or left to view more photos.

5.1.4 Shooting videos

1. Tap the to start recording video.
1. The countdown time remaining to shoot is located on the upper left; when the time left is less than a minute, the countdown turns red.
2. Point the lens to record the scene where you want to start.

Tap the icon again to stop shooting.

The time remaining to shoot counts down at the left; when less than a minute is left, the countdown turns red.



5.2 The Gallery

1. Tap the launcher and then tap Gallery .
2. Tap a folder to view the pictures or video inside in full screen mode.
3. Flick the pictures left or right to view the previous or next picture.

Chapter 6: Using Barcode Reader

This chapter explains how to use Barcode Reader and Android Winmate® Data Collection application.

6.1 Using Barcode Reader

6.1.1 Barcode Reader Location


2D Barcode Reader is an optional feature for Winmate® M101RK and may not be present in your device. Barcode Reader is located on the top side of the tablet.

6.1.2 Android Winmate® Data Collection (WDC)

The M101RK with Barcode Reader comes with pre-installed software made by Winmate® - Winmate Data Collection (WDC) that allows users to turn on the readers and set up the button to trigger the scan function.


6.1.3 Where to Find WDC

1. Tap application menu .
2. User can find the application **Data Capture (WDC)** on the menu screen, with the Globe mark .
3. User can change the settings of the Barcode Reader through WDC application.




6.1.4 How to Turn On/Off the Power of Barcode Reader

1. Go to the WDC application.
2. Tap Barcode Setting .




3. Once the user entered the WDC application, the device will automatically turn on the Barcode Reader. And the user can turn off the Barcode Reader by tapping **Barcode Power Status: ON**.



6.1.5 How to Change the Symbologies of Barcode


1. Go to the **WDC application**.
2. Tap **Barcode Settings** .
3. Tap **Barcode Preference**.
4. Users can change the symbologies of the barcode:

- 2D Symbologies
- Imager Options
- User Preference
- Disable all symbologies.



6.1.6 How to Add Command to the Barcode Output

1. Go to the **WDC application**.
2. Tap **Prefix / Suffix**.
3. Enter special characters at the beginning (prefix) or end (suffix) of the scanned barcodes.
4. Tap **Set** to add into the data.



The output will show the command that you entered in the prefix or the suffix;

For example, if user enters “\n” in the **prefix text**, the output of the barcode reader will appear on the next line of the page. And if the user enters “\n” in the **suffix**, the **output of the barcode reader** will show the barcode and change to the start of the next line for the user. Same with the command “\t” and “\b”.

6.1.7 How to Change the Scan Type of the Barcode Reader


1. Go to the “WDC” application.

2. Go to **Barcode Settings**  , tap **Trigger Settings**.

3. Select the **Scan Type** or select read time of the Barcode Reader.

To start scanning the barcode user has to leave the WDC application.


- **Auto Scan** – Barcode Reader starts auto-scanning once the user leaves the WDC application.
- **Multiple Scan** – After pressing the trigger button Barcode Reader starts continuously scanning and reading **multiple codes** within the time duration specified in **Read time option**.
- **Continuing Scan (default)** – After pressing the trigger button Barcode Reader can scan and read only a **single code** within the time duration specified in **Read time option**.




6.1.8 How to Change Volume Button to Barcode Trigger Button

To set up trigger button:


1. Put the finger on top of the screen and drag the screen from the top to the bottom.



2. Status bar will appear on the screen and will show the notifications of the device.




3. Tap on WDC icon “Sound Volume as normal use” to change the physical buttons into scan button.
4. Go back to the status bar and make sure the icon change to “Sound Volume as scan button” DO NOT TAP IT THIS TIME!



5. The volume button is on the rear side of the device.
6. Press the button to trigger the barcode reader.

6.1.9 How to Change WDC Settings or Reset to Default


1. Go to the **WDC** application.
2. Tap **Settings**.
3. Users can select the options to change the setting of the application.
4. Users can reset to the default setting by tapping **Reset setting**.



6.1.10 Scanning Barcodes

How to scan a barcode:

1. Press the function button to trigger the barcode.
2. Aim the barcode.
3. Ensure the entire barcode is within the rectangular area formed by the brackets in the laser framing.



4. Release the trigger.

6.1.11 Scanning Tips and Considerations

Distance

Scanning device will decode perfectly over a certain working range, there are minimum and maximum distance from the barcode. To specify the appropriate working range per barcode type is through a table as follows.

Symbology	Density	Min Distance	Max Distance
Code 39	0.100 mm	9.5 cm	11.5 cm
	0.125 mm	8.0 cm	14.5 cm
	0.500 mm	6.5 cm	50 cm
	1.000 mm	9.5 cm	75 cm
EAN / UPS 100%	0.33 mm	6 cm	34 cm
DataMatrix	0.18 mm	7.5 cm	16.5 cm
	0.25 mm	6.0 cm	23.0 cm
	0.38 mm	5.5 cm	34.5 cm
PDF417	0.25 mm	5.5 cm	26 cm
	0.38 mm	6.5 cm	37 cm

Angle

Scanning angle is important for promoting quick decodes.

Scanning Angle	Horizontal 34.4°	34.4°
	Vertical	22.2°
Framing Angle	Horizontal	30°
	Vertical	20°

6.2 Replacing Hot Swappable Battery

The tablet computer supports hot-swapping of batteries, meaning the tablet doesn't need to be powered off in order to replace the main battery. To support such mechanism, there is a backup battery inside the tablet that is charged up with the main battery. This backup battery cannot be removed, and needs to have adequate power for hot swapping of main battery to be done without issue. When the backup battery is fully charged, it can sustain up to 5 minutes of runtime to allow for battery hot-swapping.

Perform the following to hot swap the batteries:

1. While the tablet is powered on, go to Win-set utility to check on the power level of the Backup battery.
2. If the Backup battery level is at "Low", please charge the tablet with AC Power until the Backup battery level is at "Medium" or "High", and do not remove the main battery.
3. If the Backup battery level is at "Medium" or "High", continue to remove the main battery.
4. Insert a new charged up removable battery into the battery compartment.
5. Go to Win-set utility to check if Main battery level can be correctly read. If not, check if the new removable battery is inserted properly.
6. If Main battery level can be read, continue to use the tablet computer.




Caution

To keep battery health and prevent possible issues from battery over-discharged, please charge the tablet built-in back-up battery once for every 2 months.

6.3 Docking Connector Pin Definition

M101RK tablet computer supports one 19-pin docking connector at the bottom side. The pin definition is listed as the following table.



19 Pin Docking Connector			
Pin No.	Description	Pin No.	Description
1	RF_GND	11	NC
2	DOCK_DET #	12	NC
3	GPS ANT	13	GND
4	RF_GND	14	Power
5	RF_GND	15	USB+
6	NC	16	USB-
7	NC	17	GND
8	DETECT+	18	GND
9	Power	19	DETECT-
10	Power		

Appendix

Appendix includes additional product information, including technical specifications; order information, OS image and OTA update procedures.



Appendix A: Basic Troubleshooting

Problem	Solution
The removable battery is not charging.	<ul style="list-style-type: none"> • Make sure the AC adapter is properly connected, and that the removable battery is properly inserted.
Nothing appears on the screen.	<ul style="list-style-type: none"> • The tablet computer may be in sleep mode. Press the power button to wake up the display. • The brightness level may be too low. Increase brightness.
The screen suddenly turns blank and the power indicator goes off.	<ul style="list-style-type: none"> • Make sure that LED indicator is not powered off in Win-Set. • Make sure the AC adapter is properly connected. • If running on battery power, the battery may be depleted, charge the battery.
Wireless LAN signal quality is poor.	<ul style="list-style-type: none"> • The tablet computer may be out of range. Move the tablet computer closer to the access point or another wireless LAN device associated with it. • Check if your surroundings have interferences, such as microwave ovens, cordless phones. Move the tablet computer away from objects causing interference.
I cannot connect to another wireless LAN device.	<ul style="list-style-type: none"> • Make sure that wireless LAN feature is powered on. • Make sure that the SSID setting is the same for every wireless LAN device in the network. • Restart the tablet computer. • Make sure the IP address or subnet mask setting is correct.
I cannot connect to another device with Bluetooth.	<ul style="list-style-type: none"> • Make sure that both devices have Bluetooth powered on (For the Tablet Computer, check Win-Set to see if Bluetooth is powered on). • Make sure that the distance between the two devices is within 10 meters and there are no walls or large obstructions between the devices. • Make sure the both devices are powered on and configured to be discoverable. • Make sure that both devices are compatible.
The GPS application cannot find my location.	<ul style="list-style-type: none"> • Make sure that GPS is powered on in Win-set. • Make sure that GPS receiver and the location sensor are enabled in Control Panel. • The tablet computer may be out of coverage area. Move your tablet computer outdoors or closer to a window. • Check if your surroundings have interferences, such as microwave ovens, cordless phones. Move the tablet computer away from objects causing interference.

No sound is produced.	<ul style="list-style-type: none">• Adjust volume of the tablet computer by pressing on the volume rocker.• If using an external audio device, make sure that the cable is properly connected.
I cannot project the tablet computer display to another monitor.	<ul style="list-style-type: none">• Make sure the VGA driver is installed.• Make sure the output setting selected is correct.
Barcode scanner does not emit laser beam and does not seem to work.	<ul style="list-style-type: none">• Make sure the Barcode scanner device is enabled in Win-set utility.
Barcode Scanner emits laser beam but does not read barcode presented to it.	<ul style="list-style-type: none">• Adjust the distance between barcode scanner of the device and the barcode being scanned.• Make sure the barcode code type is enabled in the tablet. To enable/disable a specific barcode code type, go through the “Barcode Scanner Configuration” section.
I am having GPS accuracy issue	<ul style="list-style-type: none">• When utilizing the GPS function, we recommend disabling the Barcode Reader in Win-Set to reduce interference.
RFID scanner does not seem to work.	<ul style="list-style-type: none">• Make sure the RFID device is enabled in Win-Set utility.
Battery leaking or swollen	<ul style="list-style-type: none">• The lithium battery used in this tablet may swell after being charged/ discharged many times, but there is no problem regarding safety.• Continued use in such a state may result in the battery getting jammed, so please stop using the battery, and purchase a new one.

Appendix B: Product Specifications

		Model Name
		M101RK
Display Specification	Size	10.1"
	Resolution	1920 x 1200
	Brightness	800 (typ.)
	Contrast Ratio	800:1
	Viewing Angle	85/85/85/85
	Touch	Projective Capacitive Multitouch
	Panel Viewability	Optical bonding for sunlight viewability
	Technology	Anti-reflective and anti-glare technology (Optional) Automatic screen rotation
System Specification	Processor	ARM Dual-Core Cortex-A72 up to 2.0 GHz + ARM Quad-Core Cortex-A53 up to 1.5 GHz
	System Memory	2GB
	Storage	16GB eMMC
	Operating System	Android 7.1
Wireless Communications	WLAN	802.11 a/b/g/n/ac
	Bluetooth	Bluetooth 4.2
	GPS	Supports GPS
	WWAN	GSM/UMTS/LTE (Optional)
Interfaces Buttons Indicators Sensors Security	Audio	1 x built-in Mic 2 x 1W Speaker
	Interface	1 x 19-pin docking connector 1 x Micro HDMI 1 x USB 3.0 Type C (OTG) 1 x USB 3.0 Type A 1 x Power Jack 1 x Micro SD Slot 1 x Audio Combo Conn. (Mic in / Line Out)
	Buttons	1 x Power Button 1 x Home key 1 x Back key 1 x Menu key 1 x Volume up 1 x Volume down
	LED Indicators	1 x Status indicator
	Sensors	Light Sensor , G-Sensor, Gyroscope, E-Compass
	Security	Kensington Lock

Data Capture	Camera	Rear: 8MP Auto-Focus Camera with LED Flash Front: 2 MP Camera with built-in microphone
	Data Capture	Optional 1D/2D Barcode Reader
		Optional NFC Reader
Mechanical and Environment	Operating Temp.	-20°C ~ +60°C (AC Mode), -10°C ~ +50°C (Battery Mode)
	Humidity	10 to 90% RH, non-condensing
	IP Proof	IP65, dustproof and waterproof
	Shock	MIL-STD-810G Method 516.6 Procedure I
	Vibration	MIL-STD-810G Method 514.6 Procedure I
	Drop	MIL-STD-810G Method 516.6, 4 ft, Free to concrete
	Dimensions	271.67 x 198.2 x 21 mm (10.7 x 7.8 x 0.83 inches)
	Weight	0.99 kg (1.98 lbs)
Power Management	Power Input	19V DC
	Battery	7.4V, typ., 5140 mAh Li-Polymer Battery (2S1P)
	AC Adapter	110-240 AC to 19V DC out Power Adapter
	Battery Operating Time	Std. Battery: 8hours*
	Adapter	100-240V/ 12V DC 3A

Appendix C: Order Information

M101rk Series available in the following configurations:

	LTE	1D/2D Barcode Reader*	NFC Reader
M101RK	N/A	N/A	Optional
M101RK-BM	N/A	Default	Optional
M101rk-4E	4G/LTE for Europe	N/A	Optional
M101rk-4EBM	4G/LTE for Europe	Default	Optional
M101RK-LA	4G/LTE for North America (u-blox)	N/A	Optional
M101RK-LABM	4G/LTE for North America (u-blox)	Default	Optional

Appendix D: Software Development Kit

Winmate® provides the following drivers for M101rk.

Item	File Type	Description
1	M101RK Drivers	Android Debug Bridge(ADB) Driver / USB Driver
2	M101RK Flash Tool	Flash Tool

Winmate® provides Software Development Kit (SDK) for M101RK.

Item	File Type	Description
1	General SDK (WDC)	Development kit for WDC, including Barcode Reader and Fingerprint Scanner

Download SDK from Winmate Download Center.

Winmate Download Center:

<http://www.winmate.com> > Support > Download Center > Rugged Tablet > M101RK

Appendix E: OS Image Update

Winmate provide OS Image update tool. Refer to “OS Image Update Tool Guide” for a detailed instruction on how to update OS image.

Download OS Image update tool and OS Image Update Tool Guide from Winmate Download Center.

Winmate Download Center:

<http://www.winmate.com> > Support > Download Center > Industrial tablet> M101RK > OS Image

Appendix F: OTA Update Guide

You can use online OTA Update tool to update firmware version.






Important



Battery capacity must not be lower than 30% during update.

To update OTA:

1. Select **OTA-firmware**.
2. Select **Manual check**.
3. Check "I agree to update" and click "**UPDATE**".



4. Wait for download finish it will take some time.
5. Click "**REBOOT NOW**".
6. Wait while Ota is updating.





Winmate Inc.
9F, No.111-6, Shing-De Rd., San-Chung District,
New Taipei City 24158, Taiwan, R.O.C
www.winmate.com

